

Installation of the Kodiak H-2 1911 Mount

1. Install the base to your Aimpoint with the included screws. I recommend having the locking piece on the LEFT side of the dot and the intensity knob on the RIGHT side of the mount that says Kodiak Machine.
2. Remove the locking piece from the mount and back out the 2 small set screws to flush with the inside of the locking piece.
3. Slide the mount onto your rail. The cross slot you plan on using must be opened to a width of .195 to accommodate the larger lock screw with the Kodiak mount.
4. Install the locking screw into the lock piece to just snug. At this point tighten up the 2 small set screws to just snug. Then go back and tighten the locking screw another 1/16-1/8 of a turn and then do the same on the small set screws.